





## Two indicators in tandem will indicate whether a catheter is centrally located or not.

- 1. Insertion location: Placed in arm, chest, neck, and groin.
- 2. Tip terminates in the Superior Vena Cava (SVC) or Inferior Vena Cava (IVC).

Promote standardized practice.

Learn more at medlineuniversity.com