

Step 1: Logging in and overview

- 1. Login to Aruba Central using your assigned account at https://portal.central.arubanetworks.com/global_login/login
- 2. Confirm your company and group you want to modify/create.




Step 2: Creating a new group

- 1. Groups can be thought of as Instant Clusters. Each group is a 'template' that AP's are assigned to. Each group has a specific configuration that the AP will received once assigned to a group and cloud configured.
- 2. Crete a new group by clicking the + icon and name accordingly.



3. AP Assignment to group is either done by your VAR or distributor under "Global Settings"




Step 3: Creating a configuration


1. Select the group you want to modify/create the configuration for. Confirm it's selected at the top



The Apex Technolog... > OdysseyRe



2. Go through each portion and configure as necessary



- 3. Network houses the SSID configuration
- 4. Access Points house the specific access point configuration. This is not for the Virtual Controller
- 5. RF is straightforward
- 6. Security houses ACLs, Servers, Roles, etc
- 7. VPN is for tunneling
- 8. DHCP houses scopes for users, APs, devices, etc.
- 9. Services houses all advanced services like AirGroup
- 10. System is the Virtual Controller configuration

Step 4: Deploy APs

- 1. When AP's are powered on and report to Central, they will get their configuration and come online. This is done with zero touch to the end user. The VAR/distributor is responsible for making sure the AP's report to your portal.
- 2. Monitoring will show you historical data just like Airwave but with a smaller retention policy.
- 3. Reporting will allow you to run reports for the last 30 days on network performance, health, uptime, etc.
- 4. Notifications can also be configured through Central under Monitoring
- 5. Maintenance contains firmware update procedures. You can schedule or update on the fly as necessary.