#### **SPE** Distinguished Lecturer Program



The SPE Distinguished Lecturer Program is funded principally through a grant from the **SPE Foundation**.

The society gratefully acknowledges the companies that support this program by allowing their professionals to participate as lecturers.

Special thanks to the American Institute of Mining, Metallurgical, and Petroleum Engineers (AIME) for its contribution to the program.

Society of Petroleum Engineers Distinguished Lecturer Program www.spe.org/dl



# A Twenty-Five Year Perspective on Use of Pressure Transient Analysis

Robert H. Hite Shell International E&P (ret.)

Blue Ridge PTA, Inc.

Society of Petroleum Engineers Distinguished Lecturer Program www.spe.org/dl


#### What's in the Title?

Twenty-five Years



1983
Tektronix 4014
Pressure Analysis
Workstation
PAWS
Cost 72,000 USD

## Log-Log Diagnostic Plot Bourdet 1983



#### What's in the Title?

- Twenty-five Years
- Use of Pressure Transient Analysis (PTA)
  - This lecture illustrates how we have used PTA in the last 25 years. By understanding that, you can use this technology better in the future.


#### The Three Big Questions

- Why do we do it?
- How can we do it better?
- What's the big picture?


#### Why Do We do Well Tests?

- Fluids (gas or oil, PVT, surface processing issues, pipeline design)
- Rate Reservoir (permeability)
- Rate Completion (skin, length, conductivity)
- Continuity (compartments, drainage area, nearby boundaries)


## Rationales for Exploratory and Appraisal Well Tests









## Skin Analyses on Gulf of Mexico Wells







## Permanent Downhole Pressure Dataset



## Optimum Value Testing






Produce Liquids to Tanker

2001

## Wireline Formation Tester Mini Drill Stem Test




Another observation probe possible at 4.5 or 7m

Observation while Producing

**Producing Interval** 

# Distribution of Perm, 53-ft Thickness, $K_{avg} = 106$ md

Distance from well(ft)



#### **Practical Deconvolution**




Fig. 1. Test Example 1. Pressure (markers) and rate data




Fig. 4. Test Example 1. Comparison of deconvolved responses derived from PBU 1 and PBU 2 pressure data using the initial reservoir pressure of 6314.3 psi.

SPE 90680 by M. Levitan, et al.






Fig. 2. Test Example 1. Comparison of deconvolved responses derived from PBU 1 (red) and PBU 2 (blue) pressure data using the initial reservoir pressure of 6310 psl.


#### **How does Perm-Thickness** Change?




#### What is a horizontal well?




#### Varying Numbers of Beds in 88degree Slant Well



#### What is a horizontal well?



#### Varying Numbers of Beds in 88degree Slant Well



#### **Summary and Conclusions**

- Why do we do it?
  - Pie chart 21-test 1993-lookback
  - Continuity test thin beds
  - Skin distributions
- How can we do it better?
  - Permanent downhole gauges for well and reservoir management
  - Wireline Formation Tester cheaper, safer, and greener but more information

#### **Summary and Conclusions**

- What's the big picture?
  - PTA results versus petrophysical lab perm data
  - Geological layering for accurate interpretation of horizontal wells
- Most examples are from Gulf of Mexico but principles are universal.

# Backup & Extras


## Estimation of PTA Perm from Petrophysical Data




Ratio of PTA Perm to Petrophysical Perm




## Rationales for Exploratory and Appraisal Well Tests



## Shell Offshore Inc. Average Ultimate Recovery




#### 1999 Deepwater Initial Well Rates




## Optimal Value Testing What is it?

- Fit for purpose with lowest cost and HSE impact
- Any test where hydrocarbons are not produced directly to surface
  - New in toolbox
    - → Wireline formation test
      - Closed system test
      - Injection test

#### **Comparison of Permeability Estimates**




## Sequential BU's Showing Loss of H



**→** K\*H **→** Skin

## Pseudo-Skin Factors for Slant Wells



#### **Holistic Well Testing**

- All of the input data
- All of the gauges
- All of the build-up
- All of the build-ups
- All of the production history
- All of the non-well test data
  - Operational
  - Petrophysical
  - Geological